

## HINTS AND TIPS




### 5MP wifi camera: Email alert

This hints and tips will show you how to get an alert by e-mail every time there is motion. This one is used with a free Google Gmail account. Use the settings or principle for other email accounts. The principle is that when there is motion in front of the camera, the camera sends a still via e-mail to an e-mail address. In order to do this you have to a few steps.

#### Change Gmail settings



Bring up Google account. If you don't know, google 'Google account'. Log in.

Click on Security, scroll down and turn 'Less secure app access' on. This will allow the camera to use the Gmail to send.




## Open settings

Open your app, check the camera says online. (under the name). Click the cog icon for settings.




## Motion recording

Click on 'Alarm settings' and make sure the Motion Detection is on (Green). Alter the sensitivity at the bottom by sliding the level to 100. You can always reduce this later. Click apply button. Click the back arrow at top.



Click on 'Action with Alarm' in main menu. Make sure E-mail Alarm with Pictures is on (Green).



## Setup email settings

Go back to the main menu and click on 'Email Settings' near the bottom.

In the e-mail settings.

Type in:

**SMTP Server:**  
**smtp.gmail.com**

**Server port: 465**

**Encrypt type: SSL**

**Authentication: On (Green)**

**Username: (Your google username)**

**Password: Your Google password**



**Send to: The email address you want to send to**

**Sender: The email address you want it sent from**

**Subject: Subject of email**

**Message: Write a message that will send via email.**

Click the Test button to test. If said error, check that you broadband in on and all the settings. Check your e-mail.



When the camera is triggered, it should send you an email with a high resolution image enclosure. 2560x1920.

Hope this helps and you are up and running. Any problems please contact us.

support@handykam.com - **01209 313 579**

Tel: (01209) 313579 - Email: sales@handykam.com  
A division of Mike Nash Ltd - Company Reg: No.3455137 VAT: 924901722

# HANDYKAM.COM

© HANDYKAM.COM V.1